


Canon ImageRUNNER Advance DX: Copying

Using the COPY feature on the Canon ImageRUNNER Advance DX model.

1. Place document face up in document feeder or face down on the glass platen.



2. Select the **Copy** icon from the Main Menu screen.




3. Use the 10-key pad to change the quantity of copies.

Note: If making more than one copy, select **Copy Sample** to print one copy for inspection before printing out total number of copies requested.



4. Select features for coping, such as stapling under the **Finishing** icon, duplexing under the **2-Sided** icon



5. Select **Options** if necessary to add special features such as making booklets, adding covers, page numbering or job build.

6. Press the green **START** button to begin copying.



1. To stop the job running, either press the **Cancel** button or if the status window is closed, press the **Stop** button.

